


Zephyr Workshop –

BLE Two-board setup for hands-on BLE development



What is BLE?

- Bluetooth Low Energy = short-range, low-power wireless communication
- Used in wearables, sensors, smart home devices
- Optimized for brief data exchange sessions



BLE Roles in Zephyr



Peripheral

Broadcasts services

Advertises availability



Central

Scans for peripherals

Initiates connections



Data Exchange

Read/write/notify

GATT characteristics

Advertising &

Scanning

- Peripheral broadcasts name & UUID

- Central scans and parses

- Power vs interval tradeoffs



Connection Process (GAP)

Advertising

Peripheral broadcasts
availability

Parameters: interval, latency, timeout

CONNECT_REQ

Central initiates connection

Link Established

Data exchange begins

Peripheral: Publishing



Use GATT services



Heart Rate Service example



Notifications = async data push from server to client



BLE Sample: Peripheral HR


- Path: samples/bluetooth/peripheral_hr
- Board: nrf52dk/nrf52832

```
west build -b nrf52dk/nrf52832
```

```
samples/bluetooth/peripheral_hr
```


```
west flash
```

- Save the peripheral mac addr printed on the screen



address:
00:1A:23B-400-5E

Central: Receiving Data



BLE Sample: Central

HR

- Path: samples/bluetooth/central_hr
- Board: nrf52840dk/nrf52840


In **device_found** after the print add:

```
if (strncmp(dev, PERIPH_ADDR, 17) != 0)
{
    printk(" (not ours)\n");
    return;
}

printk("\n");
```

In **notify_func**: print the data[1] instead of data

- Build and flash



Exercise Demo

Steps

1. Connect both boards to USB
2. Flash peripheral_hr to nRF52DK
3. Flash central_hr to nRF52840DK
4. Open two terminals (e.g., minicom)
5. Observe advertisement, connection, and data transfer